

Programming the SECURILOCK

NOTE: Two PATS keys are required to program the SECURILOCK

NOTE: IMPORTANT: Each of the following steps should be completed with no more than 5 seconds delay between steps.

1. Insert the first ignition key and turn to the run position. Watch for the PATS light to turn off. Remove the first key.
2. Insert the second ignition key and turn to the run position. Watch for the PATS light to turn off. Remove the second key.
3. Press and hold the remote start button for 3 seconds. The PATS light should stay on for 3-5 seconds before turning off, which means that the SECURILOCK was successfully programmed.

NOTE: If the PATS light blinks rapidly, repeat steps 1-3 to retry programming the SECURILOCK.

NOTE: The engine will start if the Remote Start kit has been installed correctly, the brake is not depressed, and the hood and doors are closed.

3. Place a key in the ignition and turn to the RUN position.
4. Depress the brake pedal and place the transmission selector lever in gear. The vehicle should run without interruption